


**Important !**

Disconnect power to the main board before making any changes to DIP switches/Jumpers and while wiring the unit .



**meitav-tec**

Tel: 03-9626462  
 Fax: 03-9626620  
 e-mail: support@meitavtec.com

Title:

**CTU4601/IN/01**

Date: **20.12.09**

1

Original with BT

20.12.09

Print name :PS-2600-ASU

Software name: 09117401

Check sum : 0786

File: CTU4601-IN-01.vsd

Drawn: M.Ruchansky

Checked: S.Lukin

Approved: E.Roy